

Part #T8032 Evolution Conversion Set for Traxxas 1/10 Stampede 2WD

Body Mount Installation Tips

FRONT: Angle pieces (A.) attach to front bridge (B.). Front bridge attaches to front shock tower (C.). FRP front plate (D.) attaches on top of the angle pieces. Front body posts (E.) attach to FRP front plate.

REAR: Support posts (1.) attach to rear shock tower (2.). FRP rear plate (3.) attaches on top of the support posts. Rear body posts (4.) attach to FRP Rear plate.



